

2009 Camera Compatibility Chart - Video Camcorders

Model	TBC-312	TBC-303	SLDC-202	XNDC-28	XNDC-58	TBC-304	PSL-46	QPB-4	SLDC-203	XNDC-48	TBC-305
Video Camcorders											
Canon											
VIXIA HF11					x	x	x	x	x	x	x
VIXIA HF10					x	x	x	x	x	x	x
VIXIA HF100					x	x	x	x	x	x	x
VIXIA HG21					x	x	x	x	x	x	x
VIXIA HG20					x	x	x	x	x	x	x
VIXIA HV30					x	x	x	x	x	x	x
VIXIA HG10					x	x	x	x	x	x	x
VIXIA HR10					x	x	x	x	x	x	x
VIXIA HV20					x	x	x	x	x	x	x
FS11					x	x	x	x	x	x	x
FS10					x	x	x	x	x	x	x
FS100					x	x	x	x	x	x	x
DC330					x	x	x	x	x	x	x
DC320					x	x	x	x	x	x	x
DC310					x	x	x	x	x	x	x
ZR950					x	x	x	x	x	x	x
ZR930					x	x	x	x	x	x	x
ZR900					x	x	x	x	x	x	x
Sony											
HDR-SR12					x	x	x	x	x	x	x
HDR-SR11					x	x	x	x	x	x	x
HDR-HC9					x	x	x	x	x	x	x
HDR-SR10D					x	x	x	x	x	x	x
HDR-CX12					x	x	x	x	x	x	x
HDR-SR10					x	x	x	x	x	x	x
HDR-TG1		x	x	x	x						
HDR-UJ20					x	x	x	x	x	x	x
HDR-UJ10					x	x	x	x	x	x	x
DCR-SR220D					x	x	x	x	x	x	x
DCR-SR220					x	x	x	x	x	x	x
DCR-SR85					x	x	x	x	x	x	x
DCR-SR65					x	x	x	x	x	x	x
DCR-SR45					x	x	x	x	x	x	x
DCR-DVD910					x	x	x	x	x	x	x
HDR-UJ10					x	x	x	x	x	x	x
DCR-DVD810					x	x	x	x	x	x	x
DCR-DVD710					x	x	x	x	x	x	x
DCR-DVD610					x	x	x	x	x	x	x
DCR-HC62					x	x	x	x	x	x	x
DCR-HC52					x	x	x	x	x	x	x
JVC											
GZ-MS100		x		x	x	x					
GZ-MG330		x		x	x	x					
GZ-MG335		x		x	x	x					
GZ-MG360		x		x	x	x					
GZ-MG365		x		x	x	x					
GZ-MG730		x		x	x	x					
GZ-HD40					x	x	x	x	x	x	x
GZ-HD30					x	x	x	x	x	x	x
GZ-HD10					x	x	x	x	x	x	x
GZ-HD3					x	x	x	x	x	x	x
GZ-HD5					x	x	x	x	x	x	x
GZ-HD6					x	x	x	x	x	x	x
GZ-HD7					x	x	x	x	x	x	x
GR-DA30US					x	x	x	x	x	x	x
GR-D870					x	x	x	x	x	x	x
GR-D850					x	x	x	x	x	x	x
Panasonic											
HDC-HS100					x	x	x	x	x	x	x
HDC-SD100					x	x	x	x	x	x	x
HDC-SD9					x	x	x	x	x	x	x
HDC-HS9					x	x	x	x	x	x	x
HDC-SX5					x	x	x	x	x	x	x
HDC-SD5					x	x	x	x	x	x	x
SDR-S7		x	x	x	x	x					
SDR-SW20		x	x	x	x	x					
SDR-S10		x	x	x	x	x					
SDR-H60					x	x	x	x	x	x	x
SDR-H40					x	x	x	x	x	x	x
SDR-H200					x	x	x	x	x	x	x
SDR-H18					x	x	x	x	x	x	x
VDR-D50					x	x	x	x	x	x	x
VDR-D310					x	x	x	x	x	x	x
VDR-230					x	x	x	x	x	x	x
VDR-D220					x	x	x	x	x	x	x
VDR-D210					x	x	x	x	x	x	x
VDR-D200					x	x	x	x	x	x	x
PV-GS90					x	x	x	x	x	x	x
PV-GS320					x	x	x	x	x	x	x
PV-GS85					x	x	x	x	x	x	x
PV-GS83					x	x	x	x	x	x	x
PV-GS80					x	x	x	x	x	x	x
Flip											
Flip Video	x										
Flip Ultra	x										
Flip Mino	x										
Kodak											
Z16	x										